


EB Valve Flow Capacity



PRE-SETTING	Pre-setting Nr.	Kv (1K)	Kv (2K)	Kvs (max)	a (2K)
EB 3/8"	1	0.10	0.10	0.10	-
	2	0.14	0.14	0.14	-
	3	0.19	0.22	0.22	-
	4	0.25	0.35	0.38	0.16
	5	0.28	0.47	0.66	0.48
	6	0.28	0.47	0.79	0.64
EB 15mm & 1/2"	1	0.10	0.10	0.10	-
	2	0.14	0.14	0.14	-
	3	0.19	0.22	0.22	-
	4	0.25	0.35	0.38	0.16
	5	0.28	0.47	0.66	0.48
	6	0.32	0.57	1.01	0.68
EB 3/4"	1	0.10	0.10	0.10	-
	2	0.14	0.14	0.14	-
	3	0.19	0.22	0.22	-
	4	0.25	0.35	0.38	0.16
	5	0.28	0.47	0.66	0.48
	6	0.35	0.66	1.50	0.80
EB 1/2" ASP/SSP	-	-	1.40	2.50	-
EB 3/4" ASP/SSP	-	-	1.40	4.50	-
EB 1" ASP/SSP	-	-	1.40	5.00	0.92

Kv is flowrate in m^3/h at a differential pressure of 1 bar

$$Kv = \frac{Q}{\sqrt{\Delta p}}$$

Q = Flowrate m^3/h

Δp = Differential pressure bar



BRITISH BUILT TO LAST